

DAY 5 REVIEW & PRACTICE PRACTICAL

Open Cisco Packet Tracer and create a new project file named 'HomeWiFiNetwork.pkt' with three PCs and one wireless router connected appropriately.

ANS:

Step 1: Open Cisco Packet Tracer, create a new project file, and save it as **HomeWiFiNetwork.pkt**.

Step 2: Go to **Wireless Devices** in the device-type selection menu and place a wireless router (such as the **WRT300N**).

Step 3: Go to **End Devices** and place **three PCs** (or laptops/wireless-enabled devices) in the workspace.

Step 4: Replace the standard Ethernet NIC on each PC with a wireless module (e.g., **WMP300N**), and verify that the devices automatically associate with the wireless router's SSID.

Assign static IP addresses to each PC in your Packet Tracer network so they are on the same subnet (e.g., 192.168.10.x), and configure the default gateway to the router's IP.

ANS:

Step 1: Click on **PC 0**, navigate to the **Desktop** tab, and select **IP Configuration**.

Step 2: Set the IP configuration details for each PC within the **192.168.10.x** subnet:

- **PC 1:** IP Address: **192.168.10.2**, Subnet Mask: **255.255.255.0**, Default Gateway: **192.168.10.1**
- **PC 2:** IP Address: **192.168.10.3**, Subnet Mask: **255.255.255.0**, Default Gateway: **192.168.10.1**
- **PC 3:** IP Address: **192.168.10.4**, Subnet Mask: **255.255.255.0**, Default Gateway: **192.168.10.1**

Step 3: Ensure the wireless router's LAN IP address is configured as **192.168.10.1** to match the default gateway assigned to the PCs.

Test connectivity by using the Packet Tracer 'ping' tool to verify that all PCs can communicate with each other and the router.

Hint: Use the Command Prompt tool on each PC and type 'ping [other PC's IP]'.

ANS:

Step 1: Click on **PC 1**, open the **Desktop** tab, and select **Command Prompt**.

Step 2: Type **ping 192.168.10.3** (PC 2's IP) and press Enter to verify communication between end devices.

Step 3: Test connection to the remaining devices and gateway by pinging PC 3 (**ping 192.168.10.4**) and the router (**ping 192.168.10.1**) to ensure successful packet delivery across the wireless home network.

Document each step you took to build and configure your Packet Tracer network, including screenshots of your topology and the IP configuration windows for each PC, in a Word or PDF file.

ANS:

UPLOAD IN GITHUB